

HOSE REEL NOZZLES



N-01-1 N-01-2

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-01-1	Jet/Spray	6mm	3/4"(19mm)	>24/41	>11.2	
N-01-2	Jet/Spray	7mm	1"(25mm)	>31/53	>11.2	LPCB



N-02-1 N-02-2

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-02-1	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	
N-02-2	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	



N-03-1 N-03-2

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-03-1	Jet/Spray	6mm	3/4"(19mm)	>24/41	>11.2	LPCB
N-03-2	Jet/Spray	7mm	1"(25mm)	>31/53	>11.2	LPCB



N-04-1 N-04-2

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-04-1	Jet/Spray	6mm	3/4"(19mm)	>24/41	>11.2	LPCB
N-04-2	Jet/Spray	7mm	1"(25mm)	>31/53	>11.2	LPCB



N-05 N-06

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-05	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	
N-06	Jet/Spray	9mm	3/4"(19mm)	>24/41	>11.2	



N-07 N-08

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-07	Jet/Spray	6mm	3/4"(19mm)	>24/41	>11.2	
N-08	Jet/Spray	6mm	3/4"(19mm)	>24/41	>11.2	

HOSE REEL NOZZLES



N-09-1 N-09-2 N-09-3 N-09-4 N-09-5

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-09-1	Jet/Spray	6mm	3/4"(19mm)	>24/41	>11.2	LPCB
N-09-2	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	LPCB
N-09-3	Jet/Spray	10mm	1 1/2"(38mm)	>59/102	>11.2	
N-09-4	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	
N-09-5	Jet/Spray	6mm	3/4"(19mm)	>24/41	>11.2	



N-10-1 N-10-2

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-10-1	Jet/Spray	6mm	3/4"(19mm)	>24/41	>11.2	LPCB
N-10-2	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	LPCB



N-11-1 N-11-2 N-11-3 N-11-4

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-11-1	Jet/Spray	6mm	3/4"(19mm)	>24/41	>11.2	LPCB
N-11-2	Jet/Spray	6mm	1"(25mm)	>39/68	>11.2	LPCB
N-11-3	Jet/Spray	6mm	3/4"(19mm)	>24/41	>11.2	LPCB
N-11-4	Jet/Spray	6mm	1"(25mm)	>39/68	>11.2	LPCB



N-12-1 N-12-2

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-12-1	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	
N-12-2	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	



N-13-1 N-13-2 N-13-3

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-13-1	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	
N-13-2	Jet/Spray	10mm	1 1/2"(38mm)	>59/102	>11.2	
N-13-3	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	



N-14-1 N-14-2

Model No.	Setting	Nozzle diameter	Inlet size	Flow rate at 2bar/ 6bar (L/Min/Jet/ Spray)	Throw range at 2bar	Certificate
N-14-1	Jet/Spray	12mm	1 1/2"(38mm)	>90/156	>11.2	
N-14-2	Jet/Spray	8mm	1"(25mm)	>39/68	>11.2	